



**REFER TO TEXT ENTRY OVERLAY ON REVERSE**

- A. To enter a line of text:
  1. Press TEXT entry control (LED lit).
  2. Press LINE #.
  3. Press numerical value of desired line #.
  4. Press ENT (An asterisk will appear at start of desired line).
  5. Press SPACE or SKIP control to position symbol at desired location.
  6. Press appropriate character keys in sequence for desired annotation.
  7. Press TEXT control (turn LED off) to exit text entry mode if desired.
  
- B. To remove a line of user entered text:
  1. Press TEXT control (LED lit).
  2. Press LINE #.
  3. Press numerical value of desired line #.
  4. Press CLR to remove user text.
  5. Press TEXT control (turn LED off) to exit text entry mode if desired.
  
- C. To transfer a line of user entered text from one line to another:
  1. Press the TEXT entry control (LED Lit).
  2. Press the XFR (AVG T) control.
  3. Press LINE #.
  4. Press the numerical value of the line where the text is originally positioned.
  5. Press ENT.
  6. Press LINE # control (AVG N) again.
  7. Press the numerical value of the line # to which you want the text transferred.
  8. Press ENT. The annotation will be transferred.
  9. Press TEXT control (turn LED off) to exit text entry mode if desired.

**OPERATIONAL NOTES:SD375 TEXT ENTRY**

Do not enable TEXT entry when performing a digital plot. TEXT control ON locks out normal front panel functions. Turn TEXT control OFF when text entry mode is finished.